



 **BSRF**

The BSRF logo consists of a stylized icon made of three concentric circles on the left, followed by the letters "BSRF" in a bold, black, sans-serif font.

Index

Read first:.....	3
Description:.....	4
What's in the box:.....	4
Front Panel:.....	5
Quick start:.....	6
Measure absolute power	6
Measure insertion loss, cable loss:.....	7
Menu:.....	8
Alarm:.....	9
How to:.....	10
Useful datas:.....	12
Insertion loss of usual coaxial cables:.....	12
Insertion loss of 1:N port passive splitters (min theoric):.....	12
Accessories:.....	13
Specifications:.....	14
Warranty:.....	15

Read first:

- First of all read this manual.
- RF power can be dangerous please always use or wear proper Personnal Protective Equipment (PPI).
- Be sure to understand radiofrequency behavior when measuring power otherwise it can destroy amplifiers or hurts.
- Be sure to measure power not beyond capacity of the device or it can destroy device.
- Clean the device with a slightly damp cloth.
- This device mustn't be exposed to rain, moisture.
- Do not install the device near any heat sources.
- This device must be serviced by a qualified service personnel.
- Specifications are subject to change without notice.

Description:

First of all thanks for buying this product from BSRF, we hope it will serve you well!

The BSRF PM-1 is a broadband power meter that can be used to measure absolute RF power and also measure insertion loss of coaxial cables, filters, splitters etc... A RF power source is needed to measure insertion loss.

What's in the box:

- **PM-1:** Broadband RF Power meter.
- **PM-REF-C1:** 15cm coaxial cable, BNC male.
- **PM-AD-1:** 50ohms BNC(male)-SMA(female) adaptator.
- **PM-BAT1:** 9V alkaline battery.

Front Panel:




Illustration 1: Front panel PM-1.

The PM-1 is controlled and operated from the front panel. Result of measures are displayed on the 7-segment displays. Four leds will indicate some important informations. At last three switches are used to operate the PM-1.

LEDS:

- **On:** indicates power is on. It will blink if battery voltage goes under 7V.
- **Rel:** indicates the device displays a relative power.
- **dBm:** indicates the device displays dBm (absolute) or dB (Rel mode).
- **mW:** indicates the device displays an absolute power in milliwatt.

SWITCHES:

- **Rel:** press this switch to switch measure between absolute to relative. Press this switch 1sec to store a new reference value to make a realtive measurement (it will display 0 or almost).
- **Menu/sel:** press this switch 1sec to enter menu. While in menu press this switch to jump to following menu item.
- **On/Off:** press this switch to power on the device. Press this switch for 1sec to power down the device.

Quick start:

Measure absolute power.

- 1) Be sure the power you will measure is not above 2W(33dBm). If it is refer to measure power above 2W(33dBm) section.
- 2) Switch on the PM-1. The **REL** led must be clear, if not press shortly *Rel*.
- 3) Plug on the PM-1 the **PM-REF-C1**. At the other side of the cable plug the RF source/emitter (use an adaptor if needed). Switch on the the RF source/emitter.
- 4) Read measure on the PM-1. Press shortly *OnOff/Unit* to switch from dBm view to mW view.




Illustration 2: Connecting PM-1 to a pocket emitter.




Illustration 3: Connecting PM-1 to an IEM (BNC)

Measure insertion loss, cable loss:

- 1) First you need to use a reference RF power source/emitter., be sure the power you will measure is not above 2W(33dBm). Plug power source to PM-1 as described in "Measure absolute power".
- 2) Switch on the PM-1. Select dBm reading by pressing *OnOff/Unit* switch if needed.
- 3) Plug on the PM-1 the **PM-REF-C1**. At the other side of the cable plug the RF source/emitter (use an adaptor if needed). Switch on the the RF source/emitter.
- 4) Press Rel switch during 1s, then the led Rel will light up and **00** should be displayed. Now the led Rel will light up.




Illustration 4: While displaying power as dB press 1 sec Rel to switch to relative mode

- 5) Power off the RF source/emitter and disconnect it from the BNC cable. Plug the cable whom you want to measure loss between the **PM-REF-C1** cable and the RF source/emitter . Use the adaptator if neeeded. Then power up the RF source/ emitter. Now it will display insertion loss of cable (ex: **-32**). You can compare the measure you get from the calculated value: cable length*attenuation per meter. Some common cable insertion loss are listed in the "Insertion loss of usual coaxial cables" section of this manual.
- 6) Depending on internal circuits of IEM or pocket transmitters if you try to measure small cable or if you need max precision of measure a good habits is to add an attenuator at the output of the power source. This to reduce SWR*. You can use a 3dB or 6dB attenuator.

If you use a laboratory RF power source you should not need to add an atttenuator at the output.

(*)Standing Wave Ratio

NOTE: If you use a small power source as pocket emitter or IEM with RF power under 100mW you can avoid switching off power source when you disconnect source from cable as reflections are not able to destroy the output power amplifier of the device.

Menu:

MENU is accessed by pressing during 1s the central switch. To navigate to the next item just press again central switch. Parameters can be changed by pressing first switch (decrease) or right switch (increase). At any time you can leave MENU by pressing central switch during 1s. Following tab explains functionality of items in MENU.

Codes		Description
A0	Menu/ default value:0(dB)	<u>Attenuation/Amplification compensation (dB)</u> , max is +20dB, min is -20dB. If you connect an attenuator at the input, let's say it's a 6dB attenuation, decrease the A value to -6dB. Then when you go back to normal mode, the displayed dBm value will increase the value by 6dB to compensate for the loss. With a 6 dB attenuator the max displayed power will be +39dBm (8W). As soon as value become different from '0' the left point will blink to make you remember a compensation is applied.
U40	Menu/ default value:40(dB)	<u>Upper threshold alarm (dBm)</u> , if input power goes above this value, a beep will sound and the alarm port will be set on (internal connector, open drain).
L -20	Menu/ default value: -20(dB)	<u>Lower threshold alarm(dBm)</u> , if input power goes under this value, a beep will sound and the alarm port will be set on (internal connector, open drain).
F50	Menu/default value:50(x10 MHz)	<u>Frequency (10MHz)</u> , set it according to the frequency of the signal you're measuring, this will increase accuracy.
SER0	Menu/default value:0	<u>Serial data</u> , enable serial data emission from the PM-1. Data are available through an internal RS-232 port.
OFO	Menu/default value:0	<u>Offset</u> , used to calibrate low power response don't change it unless you have calibrated devices to do it.
GBO	Menu/default value :0	<u>Global correction offset</u> , used during calibrating process. Don't change it unless you have calibrated devices to do it.
b8	Menu	<u>Battery(Volt)</u> , voltage of the supply, from 9V battery or external, only read
E26	Menu	<u>Temperature (°C)</u> , internal temperature, in the -10/+60 range, only read.
H500	Menu	<u>Hardware Software version</u> ,only read.

Tableau 1: Menu items description.

Alarm:

Alarm has two outputs: one is an internal BUZZER and the second is an internal OUPUT (open drain output, max 100mA). As soon as an alarm is ON the output is ON.

The PM-1 is fitted with some alarm functions to give you in real-time important informations. First if you ear an continuous buzz (500Hz) this means the input power is higher than the maximum allowed power ($>33\text{dBm}, >2\text{W}$) and this could lead to failure of PM-1. As those power are quite high first power down the transmistter or amplifier conneted to the PM-1. You also can ear this buzz if internal temperature is above 60°C (340K). This temperature is too high and can be caused by the input power. Disconnect properly the equipement.

Second you can set a Upper and a Lower threshold. If input signal override the Upper threshold the BUZZER will beep. If the input signal goes under the Lower threshold the BUZZER will beep. The output port will be set if any of these alarm are active. This helps you to monitor constantly RF power.

How to:

- 1) How to measure RF power at the output of an transmitter?

First be sure the power you're going to measure won't overload the device, means power is lower or equal to 33dBm (2W). Power up your PM-1. Then plug your PM-1 to the transmitter output using quality 50ohms coaxial cables and adaptor. Then switch on your transmitter. Press the third switch to alternate view from dBm to mW and use the one you're more familiar with. Dont' forget that used cable induce RF loss, you've to take it in account. Third "how to" will tell you how to get this attenuation information.

- 2) How can know if a coaxial cable is good or not?

The best way to test a coaxial cable is to test insertion loss by putting a RF signal at a side and checking what comming out at the other side. If this value of attenuation is too low from the manufacturer datasheet this mean the cable or connectors have a problem.

The PM-1 is the ideal tool to perform this test. You just need a RF source as a transmitter (pocket or rack) with a power about 17dBm (50mW), this allows you to measure up to 37dB of attenuation, the correct adaptor (if needed) the test cable.

First plug the test cable to the transmitter and the PM-1. On "dBm" display mode the power is displayed, press for 1sec the first switch to select REL mode and store the current value (the reference). The PM-1 will display 0,00dB or almost.

Second, now connect the cable we want to test between the transmitter and the test cable (with proper adapters). As soon as this is done the amount of attenuation will be displayed. That's all: make the reference and then read.

- 3) How can I do the accurest measurement?

To do so, first take care of the frequency of measurment (the one of the transmitter) and set the Frequency compensation accordingly. Be sure to use a test/reference cable in good shape. Be aware that even the test/reference cable exhibit a small portion of insertion loss and one's could add this value to get the accurest value.

- 4) How can I measure an absolute power above 33dBm(2W). You need to add an attenuator that can stand almost the maximum power you want to measure. Enter the menu and decrease A value down to -10 and then exit menu. The offset led led will be on. [The maximum measurable power is 33dBm + Attenuator value. With a 10dB attenuator you can measure power up to 43dBm while the minimum measured power will be reduced in the same proportion. With no external attenuator the minimum measured power is about -15dBm so with a 10dB attenuator the minimum measured power will be -5dBm.]
(Note)As soon as you add an offset, the offset red led on display will light up and when you measure a power in dBm it will display compensated power (power measured -"Attenuation"). If you switch to mW it wil display measured power in mW without compensation so you can check what power really goes inside the PM-1.

- 5) How can I check power of an amplifier while emitting?To do this you'll need a directionnal coupler. This 3/4 ports passive device will let most of the power to be transmitting by the antenna while a small portion of this power will be forwarded to a coupled output where you'll plug the PM-1. This device can be use forward or backward to monitor forward power or reflected power. Set the Attenuation factor according to your coupler's "coupling factor" (for example -6,-10 or -13). Then it will display the compensated value. If you set Upper or Lower threshold alarm it will take in account the compensation but be aware that power

swing at the input must remain in the +33dBm/-10dBm (2W/1mW) or it can't measure the power. To be sure you're still in the power range, from DBM mode switch to MW mode and the PM-1 will display the measured input power without compensation (mW). If it displays : **L0 P** it means input power is to low. Consider using a coupler with a bigger coupling factor. Feel not comfortable with that please contact us at contact@bs-rf.com.

- 6) What means **L0 P** ? It means that the input power is to low to be measured. This will display as soon as the incomming RF power is under 20dBm (0,01mW). If you see this appearing during a measure it seems that you get too much loss somewhere.
- 7) What means **H LOH** ? It means that the input power is above 33dBm(2W). Avoid this situation as it can damage permanently the equipment. If after this your equipement doesnt behave correclty please contact us in order to service the equipement at contact@bs-rf.com.
- 8) How to change the battery? Remove screws and nut of BNC connector, open panel and you can change the battery.
- 9) How can I estimate loss in a coax (coax plus connectors). The minimum loss is loss occuring in the coax cable itself. From the Illustration 6: Insertion loss of usual coaxial cables per meter . you can calcs minimum loss in coax. Choose frequency(closest one from the generator frequency for example), select the type of coax used. Then multiply the value of attenuation per meter to the length of the coax. Ex: 625MHz => use 600MHz, RG316, so loss per meter is 0,7dB. If length is 50 centimeter, minimum loss is $0,7*0,5=0,35$ dB. Now you need to add loss of connectors. Loss of good connectors is about 0,05dB max. Finally the $Loss_{total} = Loss_{connector} * 2 + Loss_{coax\ cable}$; $Loss_{total} = 0,45\ dB$. If the value you get is not above twice the $Loss_{total}$, it's ok, try to bend a little cable near connectors to check that nothing break.
If the value you get from the measure is above twice the $Loss_{total}$, it's suspect. Check that the procedure to calibrate is ok. If calibration is ok the cable should be not used.
- 10) I try to measure loss in a small coax (50cm per example) and after I had set reference my measure does'nt seem ok (for example loss too low in regard of calculus or positive value meaning an amplification!). This typically happens when a impedance mismatch occured. To avoid that place an attenuator at the output of your RF power source (3dB or 6dB attenuator can be used). Then re-do the reference process and the measure. This will fix this behavior.




Illustration 5: Adding an attenuator to reduce SWR effects

Usefull datas:

Insertion loss of usual coaxial cables:

Cable (50ohms) :	Frequency						
	10MHz	100MHz	400MHz	500MHz	600MHz	700MHz	1GHz
RG316	0,1dB	0,3dB	0,6dB	0,6dB	0,7dB	0,8dB	0,9dB
RG58	0,1dB	0,2dB	0,3dB	0,4dB	0,4dB	0,5dB	0,6dB
RG213-RG214- RG8	0,02dB	0,1dB	0,2dB	0,2dB	0,2dB	0,2dB	0,3dB
LMR400	0,04dB	0,1dB	0,1dB	0,1dB	0,2dB	0,2dB	0,2dB
Ecoflex 10	0,012dB	0,04dB	0,08dB	0,1dB	0,1dB	0,1dB	0,14dB

Illustration 6: Insertion loss of usual coaxial cables per meter .

Insertion loss of connectors:

A good connector is typically 0,05dB of loss (400MHz-800MHz). You can check the datasheet of the connector to find this value.

Insertion loss of 1:N port passive splitters (min theoric):

N ports :	Min att (dB)
2	-3
3	-5
4	-6
5	-7
6	-8
7	-8
8	-9
10	-10
16	-12

Illustration 7: Minimum insertion loss of passive splitter

Accessories:

Reference:	Description:	
PM1C01	10 cm RG58, BNC-BNC male, 50 ohms	
PM1A01	I BNC female, 50 ohms	
PM1A02	Adapter, BNC male, SMA female, 50 ohms	
PM1A03	Adapter, BNC male, N female, 50 ohms	
PM1A04	Adapter, BNC female, Lemo 00.S male, 50ohms	
PM1A05	Adapter, BNC female, SMA male, 50ohms	
PM1A06	Adapter, BNC female, N male, 50ohms	
PM1M01	Rear panel with external power port connector.	Contact us...
PM1M02	1U panel to host up to 4 PM-1.	Contact us...
PM1CP01	3 ports RF coupler....	Contact us...
PM1AT01	Attenuator 6dB/10W	

Specifications:

Bandwidth	10-1000MHz	
Absolute max RF input	2,5W(34dBm)	
Max RF input	2W (+33dBm)	CW* measure
Min RF input	0,01mW (-10dBm)	CW* measure
Input SWR	1,32 max	(10-3000MHz)
Accuracy	+/-0,2dB typ.(0 to 33dBm); +/-0,4dB typ.(-10 to 0dBm)	0 to 40°C (273 to 313K)
Temperatu-re range	0 to 50°C (263 to 323K)	
Connector	BNC 50ohms	
Supply	9V battery	30mA (power on)
Supply		20µA (power off)
Autonomy	Up to 8h	(continuous)
Dimensions	84x59x31mm (3,3x2,3x1,2in)	(enclosure)
Weight	0,2kg (0,44lbs)	(w battery)

(*)mean constant wave, unmodulated carrier or FM/phase modulated.

Warranty:

The PM-1 comes with a 2 years warranty. This Limited Warranty covers any defects in material or workmanship under normal use during the Warranty Period. During the Warranty Period, BSRF will repair or replace, at no charge, products or parts of a product that proves defective because of improper material or workmanship, under normal use and maintenance.

Send us an email first at contact@bs-rf.com



Société Aeitech - Avenue de la Mauldre, 6 Village d'Entreprises, 78680 Épône
01 45 25 51 00 - info@aeitech.com - www.aeitech.com